スギノ製クランク および 一般的な5アームクランク 用の フロントシングルチェーンリングです。



シマノ12スピードおよび11スピードにて使用できます。 取り付ける前に、下記の適合クランクを確認してください。

※フロントダブルでの使用はできません。 ※クランクおよび関連製品は別売りです。

#### 適合クランク

#### スギノ OXシリーズ


- · OX3-920D
- OX2-901D / OX2-901D Classic

#### スギノ Mightyシリーズ

- · Mighty Tour 901D
- · Mighty Mignon 901D

※Mighty Mignon - 901D は旧称です。現在は、 Mighty Tour - 901D に統合されています。

#### 一般的な5アームクランク



#### 関連製品

GRV5-SWNと併せて使用する製品(別売り)です。

705 for Front Single



STI Stopper Ver.2



フロント変速用のSTIレバー(デュアルコントロールレバー) のシフティングケーブルを固定し、レバーの不要な動きを 抑止します。



#### 取り付け

【図1】

表側

チェーンリング

取り付け面

裏側

- ① クランクからチェーンリングを取り外してくだ さい。
- ② 左記の [適合クランク] を確認してください。 クランクの種類によって GRV5-SWN の取り付 け方が異なるため、以降の手順が分岐します。

#### スギノ Mightyシリーズ 一般的な5アームクランク

**α**side **Q**(side

- ③ GRV5-SWN の **α** side を表にして、クランクの チェーンリング取り付け面の表側に配置してく ださい。--【図1】【図1-A】
- ④ GRV5-SWN は上下左右の指定はありませんの で、ロゴマーキングが好みの位置にくるように してください。—【図2-A】
- ⑤ 705 for Front Single (左記参照) を取り付けて ください。-【図3】

#### スギノ OXシリーズ

**B**side

- ③ GRV5-SWN の  $\beta$  side を表にして、クランクの チェーンリング取り付け面の裏側に配置してく ださい。- 【図1】 【図1-B】
- ④ GRV5-SWN は上下左右の指定はありませんの で、ロゴマーキングが好みの位置にくるように してください。—【図2-B】
- ⑤ 705 for Front Single (左記参照) を取り付けて ください。--【図3】

#### スギノ Mightyシリーズ 一般的な5アームクランク

# スギノ OXシリーズ









# 【図3】




※ボルトにグリスを薄く塗布し、1~5の順に締め付けます。 締め付け後、全てのボルトに緩みがないか確認してくださ い。詳しくは、チェーンリング固定ボルトの取扱説明書を ご参照ください。

#### フロントシングル化に伴う注意事項

※フロントディレーラーは取り外してください。 また、STI Stopper Ver.2 (左記参照) を取り付けてください。

※GRV5-SWN は幅の異なる歯が交互に並んでいますので、歯と チェーンは 幅の広い方同士 および 幅の狭い方同士 を嵌め合わ せてください。- 【図4】

チェーンはコンポーネントに合わせて、シマノ製の12スピー ド用もしくは11スピード用のものを使用してください。



#### 安全のために必ずお守りください。

誤った取り扱いは、製品の破損や重大な事故に繋がる恐れがあります。

- ●乗車前および乗車後には各所に緩みやガタが無いか点検し、必要に応じてボルトの増し締めをしてください。
- ●定期的に各部品を点検してください。

#### 洗浄

●製品を洗浄する際の洗剤やケミカルは、必ず中性表記のあるものを使用してください。酸性やアルカリ性のものを使用 した場合、製品の外観や機能を著しく損なう恐れがあります。洗車サービスを利用される場合にも必ずご確認ください。

#### ▲ 警告

- ●適切な工具で適切な取り付けが行われなかった場合や自転車以外の用途に使用した場合、重大な事故に繋がる恐れがあ ります。
- ●マーキングや表面処理の変更、加工等の改造を行った場合、重大な事故に繋がる恐れがあります。
- 製品の取り付けや取り扱いに関して疑問のある方は販売店にご相談 ください。正しい取り付けおよび調整をされなかった場合は、破損 や重大な事故に繋がる恐れがあります。
- ●取り扱い説明書はよくお読みになった後、大切に保管してください。



Front Single chainring for Sugino crank and standard 5-arm crank for Shimano 12 Speed & 11 Speed drivetrain. Before installation, check the crank compatibility.



- \*Cannot be used for double-ring setup.
- \*Crank and fixtures not included.

#### Crank compatibility

#### Sugino OX series

- · OX3-920D
- OX2-901D / OX2-901D Classic

#### Sugino Mighty series

- · Mighty Tour 901D
- · Mighty Mignon 901D
- \*Migthy Mignon 901D is former model name. It is integrated into Mighty Tour 901D.

# Standard 5-arm crank P.C.D.110mm 5-arm Cannot be mounted on MTB crank.


#### Fixtures

Required options for GRV5-SWN (sold separately).

705 for Front Single



STI Stopper Ver.2



Install it on shifting cable to hold STI lever (dual control lever) in place.

#### Installation

- ① Remove original chainring from crank.
- 2 Check the [Crank compatibility] table. There are 2 different installation procedures depending on the crank types.

#### Sugino Mighty series Standard 5-arm crank

- 3 Place GRV5-SWN on the outside of the crank ensuring that **a**side mark is facing outwards. — [Fig.1] [Fig.1-A]
- 4 GRV5-SWN has no specific orientation. Orient it so the logo marking is positioned at your preferred position. - [Fig.2-A]
- (5) Install 705 for Front Single (see fixture options). and then tighten each bolt. — [Fig.3]

#### Sugino OX series

Bside

Important points for converting to Front Single setup

\*Remove front derailleur and use STI-Stopper Ver.2 (see

\*GRV5-SWN has alternating narrow and wide teeth, fit

narrow links on the narrow teeth and wide links on

Use Shimano 12 Speed or 11 Speed chain depending

fixture options) on the front shifting cable.

**α**side

- 3 Place GRV4-SWN on the inside of the crank ensuring that  $\boldsymbol{\beta}$  side mark is facing outwards. - [Fig.1] [Fig.1-B]
- 4 GRV5-SWN has no specific orientation. Orient it so the logo marking is positioned at your preferred position. — [Fig.2-B]
- ⑤ Install 705 for Front Single (see fixture options), and then tighten each bolt. — [Fig.3]

wide teeth. — [Fig.4]


[Fig.4]

on your Shimano component.

### Sugino Mighty series Standard 5-arm crank [Fig.1] Chainring [Fig.1-A] mounting surface Outside Inside $\alpha$ side Countersunl

Sugino OX series

(Fig. 1-B)







# [Fig.3] Tool

## Torx wrench (Size: T30) Tightening torque 6.9N·m (70kgf·cm)

\*Grease the bolts and tighten them down 1~5 in the numbered order. After installing all the bolts, make sure that they are secure. For details, see user's manual of the chainring fixing bolts.

#### Fully observe the followings for your safety.

Incorrect installation may damage the parts and leads to serious accidents.

- Before and after every ride, check all parts for play or looseness, and secure any loose parts and fasteners.
- Do regular routine checks on all parts.

#### CLEANING

• Be sure to use detergents or chemicals described as "neutral" to clean the products. Acidic and alkaline agents will harm finished surfaces and can cause malfunction to the products. When you receive a bike wash service, make sure that a neutral wash solution is use.

#### **▲** WARNING

- Please use the appropriate tool for every installation. These parts are for use as specified for the bicycle indicated and shall not be used for other purposes. Inappropriate use may lead to serious accidents.
- Please do not alter these products, including changes in logos, surface treatment and so on, as it may cause serious accidents.
- If you have questions regarding installation and handling, please contact a professional. Incorrect installation and setting may damage the parts and lead to serious accidents.
- Please read the handling manual carefully and keep it at hand.



#### **SUGINO ENGINEERING CORPORATION** The specifications are subject to change without notice

MA-Chr GRV5-SWN (EN) 2025 1127