


TL-BBSG75 Guide ring

BB-SG75シリーズの取り付け用工具

使用方法

- Park Tool製工具HCW-4などの36mmスパナと併せて使用します。
- BB-SG75の取扱説明書に従い、取り付け作業を行ってください。



安全のために必ずお守り下さい。

誤った取り付け方法では、部品の折損や重大な事故につながる恐れがあります。

点検・整備

- 乗車前には各所に緩みが無い点検し、必要に応じて増し締めをしてください。
- 定期的に各部品のメンテナンスをしてください。

警告

- 適切な工具で適切な取り付けが行われなかった場合や自転車以外の用途に使用した場合、重大な事故につながる恐れがあります。
- マーキングや表面処理の変更、加工等の改造を行った場合、重大な事故につながる恐れがあります。
- 製品の取り付けや取り扱いに関して疑問のある方は販売店にご相談のうえ取り付けを行ってください。正しく取り付け及び調整をされなかった場合は、破損や重大な事故につながる恐れがあります。
- 取り扱い説明書はよくお読みになった後、大切に保管してください。

株式会社 **スギノ エンジニアリング**
<https://www.suginold.co.jp/>

製品改良のため、仕様の一部を予告なく変更することがあります。
 ご質問等は弊社HPのお問い合わせフォームにて承っております。




MA-TL BBSG75 Guide (JP) 2021 1004

TL-BBSG75 Guide ring

Installation tool for BB-SG75 series

How to use

- A 36mm spanner (such as Park Tool : HCW-4) is required.
- Install the BB in accordance with the instruction manual of the BB-SG75.



Please fully observe the safety precautions as follow.
 Incorrect installation may damage the parts and leads to serious accidents.

MAINTENANCE

- Before every ride, check all parts for play, and secure any loose parts.
- Do regular routine checks on all parts.

WARNING

- Please use the appropriate tool for every installation. These parts are for use as specified for the bicycle indicated and shall not be used for other purposes. Inappropriate use may lead to serious accidents.
- Please do not alter these products, including changes in logos, surface treatment and so on, as it may cause serious accidents.
- If you have questions regarding installation and handling, please contact a professional. Incorrect installation and setting may damage the parts and lead to serious accidents.
- Please read the handling manual carefully and keep it at hand.

SUGINO ENGINEERING CORPORATION
<https://www.suginold.co.jp/us/>

The specifications are subject to change without notice due to continuous improvements.



MA-TL BBSG75 Guide (EN) 2021 1004